


Avalon Chair

Parts List

Item# 16600-16621




Part 1:
Chair Back
x 1 pc



Part 2:
Chair Leg
x 1 pc



Part 3:
Chair Leg
x 1 pc



Part 4:
Chair Seat
x 1 pc

Avalon Chair

Assembly Instructions

Item# 16600-16621

HARDWARE

A. Flat Washer

x 8 pcs



B. Lock Washer

x 8 pcs



C. Short Hex Bolt

6 x 40 mm,
x 8 pcs



D. Long Hex Bolt

6 x 75 mm,
x 2 pcs




Allen Wrench


x 1 pc




Step 1




Step 2




Step 3



Step 4



Complete



CAUTION: Adult assembly required.
Hardware contains small screws with sharp points. Keep unassembled parts out of the reach of small children.

USE AND MAINTENANCE:

-Use on level surfaces only
-Please check assembly at regular intervals, and periodically tighten hardware if necessary.
If maintenance is not carried out the product could overturn or fall.



WARNING: CHOKING HAZARD
Unassembled parts may be a choking hazard to children 3 years and younger.